



RECIRCULATING DOOR ACTUATOR

- 3 (OR 4) YEL/LT BLU
- 3 (OR 4) RED/WHT
- 2 (OR 5) RED/LT GRN
- 6 YEL/LT GRN
- 1 (OR 2) ORG/LT BLU

STEERING WHL CTRL POTENTIOMETER RETURN

BLOWER FBACK

- 8 BRN/LT BLU 1070
- 9 RED/WHT 438
- 10 LT BLU/ORG 269
- 11
- 12 ORG/LT BLU 1069
- 13 BRN/LT GRN 245
- 14 ORG/BLK 484 INTERIOR LIGHTS SYSTEM
- 21 WHT/ORG 790
- 22 GRY/LT BLU 688
- 23 YEL/RED 752
- 24 LT GRN/WHT 754
- 25 YEL/LT GRN 660
- 26 VIO 246

SCP BUS (-)

BATTERY

GROUND

SENSOR GROUND

RECIRC DR ACT POT. POTENTIOMETER FEED

AMB TEMP SENS INPUT

SCP BUS (+)

IGNITION

BLEND DOOR ACT

SUNLOAD SENS INPUT

- 1 PNK/LT BLU 915
- 2 RED/WHT 729
- 3 BLK 57
- 4 PNK/BLK 470
- 5 YEL/LT BLU 435
- 6 RED/LT GRN 436
- 7 LT BLU/ORG 767
- 15 TAN/ORG 914
- 16 RED/BLK 1040
- 17
- 18 YEL/LT GRN 437
- 19
- 20 BRN 468

ELECTRONIC AUTOMATIC TEMPERATURE CONTROL (EATC) MODULE

COMPUTER DATA LINES SYSTEM

- TAN/ORG
- PNK/LT BLU

AUDIO/CLIMATE CONTROL SWITCH ASSEMBLY

FAN

TEMP

422 OHMS

130 OHMS

226 OHMS

931 OHMS

2940 OHMS

AIR BAG SLIDING CONTACT

DRIVER COMMAND RTN

SPEED CONTROL SERVO

- 6 DK GRN/ORG 848

SOLID STATE

REAR AUDIO/CLIMATE CONTROL SWITCH

- 2 BRN/LT BLU 1070

HOT AT ALL TIMES

FUSE 19 10A

HOT IN RUN

FUSE 6 15A

HOT IN RUN

FUSE 2 30A

CENTRAL JUNCTION BOX

BRN/ORG

BRN/ORG

ORG/RED

ELECTRONIC AUTOMATIC TEMPERATURE CONTROL (EATC) BLOWER MOTOR

RED/WHT

S276

S252 (2000)

S252 (2001)

RED/BLK

S255

RED/BLK

269 LT BLU/ORG 1 OR 3

752 YEL/RED 2

754 LT GRN/WHT 1 OR 3

57 BLK 4

515 ORG/RED 5

BLK

S201

BLK

G203

BLWR FBCK

BLWR CTRL

HI RELAY

GROUND

BLWR DRIVE

BLWR MOTOR SPEED CONTROLLER

VIO 6

BRN/LT GRN 1

RED/WHT 3 (OR 4)

RED/LT GRN 2 (OR 5)

YEL/LT GRN 3 (OR 4)

BLEND DOOR ACTUATOR

BRN/LT BLU

2000-01 W/O LIVERY LWB

2001 W/LIVERY LWB

BLK

S207

BLK

G200

BRN/LT BLU

BRN/LT BLU

S347

RED/BLK 1

RED/BLK 2

RYL/ORG

PNK/BLK

WHT/ORG

PNK/BLK

PNK/BLK

BRN

S251

AMBIENT TEMPERATURE SENSOR

IN-CAR TEMPERATURE SENSOR

EATC SUNLOAD SENSOR

85

REAR WINDOW DEFROST RELAY

BATTERY JUNCTION BOX